

Retro fit a projector lens:

- The lens must be placed in the middle over the battery charge indicator. Mark this position with a non-permanent pen on the lamp glass before you dismantle the lamp.
- Unscrew all the screws that hold the lamp glass.
- take off the glass (optics remain on glass)
- Clean very well the spot where you want to stick the projector lens. This is very important. Best is to use a soft paper towel for this.
- Now you can fix the projector lens on the back side of the lamp glass on the spot you have marked. Use the double side scotch that came with the lens.
- Put back the lamp glass and check that the o-ring sits well.
- Tighten the screws – finished -> test 😊
-

